



Date: 1 February 2013

Software Update Procedure

The following procedure outlines the process to update the software of the Stage CL.

Parts Required

- USB Drive, with typical windows compatible formatting (FAT32)
- The update package which can be downloaded from www.jands.com/support/stage-cl-downloads.

Procedure

1. Download the software update and copy it to the root directory (top level) of your USB stick.
2. Turn on the Stage CL console and wait for the application to start
3. Insert the USB stick into the console.
4. From the “Home” screen, tap the “Settings” button, then press the “About” tab. Stage CL displays the “About” window.


| Setup | Preferences | About |
|------------------|---------------|-------|
| Item | Value | |
| Software version | 0.1.10750 / 0 | |
| Build date | Oct 26 2012 | |
| Serial number | N/A | |
| Update from USB | Update... | |
| Diagnostic tests | Run... | |

5. Scroll down to the “Update Software from USB” field, then press the touchscreen dial button to select the “Update” option. Stage CL opens the “Update Software” window.

| Setup | Preferences | About |
|------------------|---------------|-------|
| Item | Value | |
| Software version | 1.1.10841 / 0 | |
| Build date | Nov 6 2012 | |
| Serial number | N/A | |
| Update from USB | Update... | |
| Diagnostic tests | Run... | |



6. Press the “Yes” button to begin the update.



7. The update process may take a few minutes and the console will restart when it is complete. Do not turn the power off while the update is running.