

Vista T4/T2

Control Consoles

TBJLT127.doc



Date: 31 October 2008

Vista Shaking Cursor

A number of users have found the cursor on the tablet will shake sometimes at startup, usually when the console is cold. This is cured by changing the BIOS setting as follows:

1. Power console down.
2. Start console.
3. Press the "Del" button repeatedly while the BIOS messages are displayed.
4. When the blue BIOS menu is displayed, use the cursor buttons to select "Advanced Chipset Features".
5. Press Enter.
6. Use the cursor buttons to select "Video BIOS Cacheable".
7. Press Enter.
8. Use the cursor buttons to select "Enabled".
9. Press Enter.
10. Press F10.
11. Press Enter.

The console will restart.